

# INSTALLATION MANUAL




## RC-LGI Interface

The RC-LGI Interface allows easy integration of conventional infrared repeating systems with LG/Zenith flat panel televisions.

### INSTALLATION

With the power off to both the infrared connector block and the television, connect the RC-LGI interface following the wiring diagram below. Once all connections are made. Power can be restored to all the units. The system sensitivity can be adjusted via the trim pot on the input side of the RC-LGI.



### WARRANTY

Your AUDIOPLEX TECHNOLOGY® RC-LGI Interface is covered by a Lifetime Warranty against defects in workmanship and materials. Any defects will be remedied without charge for labor or parts.

Damage incurred by shipping or accident is not considered to be a defect, and not covered by this warranty. AUDIOPLEX TECHNOLOGY® is not responsible for defective operation caused by abuse or by modification or service by an unauthorized person or agency.

The unit must be properly installed and operated according to instructions for the warranty to apply. Any necessary servicing must be done by AUDIOPLEX TECHNOLOGY®. The products must be returned expenses prepaid, with written authorization from the company. The unit must be shipped with the proof of purchase and in original carton and packing material to avoid damage.

**AUDIOPLEX TECHNOLOGY®**